

# **2022+ TUNDRA POWERED SUBWOOFER INSTALLATION DIAGRAMS AND VIDEOS**

You **MUST** disconnect your negative battery terminal using a 12mm socket before beginning the installation process.

## **Battery Locations:**

### Non-Hybrid

- Under the hood on the passenger side

How to disconnect your negative terminal:

You must disconnect the terminal and wire harness at the battery

(Minute 0:00-0:20)

VIDEO: <https://www.youtube.com/watch?v=CnLGvc-571Y&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu>

### Hybrid

- Located under the rear seat on the driver's side

How to disconnect your negative terminal:

You must disconnect the terminal and wire harness at the battery

(Minute 0:00-0:22)

VIDEO: <https://www.youtube.com/watch?v=0PikxaX-lG8>

## **How to install Power wire:**

### [Hybrid](#)

DIAGRAM: <https://tacotunes.com/wp-content/uploads/2025/12/hybrid-power-wire.jpg>

### [Non-Hybrid](#)

How to get power wire through firewall:

Do NOT run to the driver's side, run on the passenger side.

VIDEO: <https://www.youtube.com/watch?v=oBov3o2fEDM&t=1s>

How to run Power wire to rear wall:

Follow the route in this video once you have penetrated the firewall.

VIDEO:

<https://www.youtube.com/watch?v=RFSbeCVnwks&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=20>

## **How to remove JBL EQUIPPED Factory Subwoofer:**

VIDEO:

<https://www.youtube.com/watch?v=dT7FojH4dkw&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=25>

## **How to Install Ground wire:**

### [Hybrid & Non Hybrid](#)

Use the ground wire location explained in this video. (minute 0:15-0:38)

VIDEO: <https://www.youtube.com/watch?v=8fZcyFGF1y8&t=11s>

## **How to Connect Plug & Play Wiring:**

### [JBL Equipped](#)

How to gain access to your JBL Amplifier (Minute 0:00-0:39)

VIDEO:

[https://www.youtube.com/watch?v=d52lg3N\\_xZ4&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=30](https://www.youtube.com/watch?v=d52lg3N_xZ4&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=30)

### [Base Audio](#)

How to remove head unit-

<https://www.youtube.com/watch?v=yjronZOBX0s&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=4>

How to connect behind the head unit and run to rear wall-

<https://www.youtube.com/watch?v=RFSbeCVnwks&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=20>

## **Plug & Play Connections:**

*JBL vs Non-Jbl instructions Included inside your corresponding drivetrain diagram*

### **HYBRID**

DIAGRAM: <https://tacotunes.com/wp-content/uploads/2025/12/Hybrid-2022-TUNDRA-PS-V3-WIRING-DIAGRAM.pdf>

### **NON-HYBRID**

DIAGRAM: <https://tacotunes.com/wp-content/uploads/2025/12/NON-Hybrid-2022-TUNDRA-PS-V3-WIRING-DIAGRAM.pdf>

## **How to Install Subwoofer Enclosure:**

### **Hybrid**

VIDEO: <https://www.youtube.com/watch?v=0PikxaX-lG8&t=386s>

### **Non-Hybrid**

VIDEO:

<https://www.youtube.com/watch?v=tMTFvbU39Dg&list=PLFuSO7p8sCy2vZG2kRnin2H9tpiQAXuKu&index=22>

## **How to tune your Powered Sub Amplifier:**

DIAGRAM: <https://tacotunes.com/wp-content/uploads/2025/12/2022-V3-TUNING-DIAGRAM.pdf>