

Power &

Fuse

Layouts

TXD1000.5 - 5 Channel Amp

Power/Fuse Layout


Connects to Battery

80 Amp fuse

Mounts by factory
fuse box/battery

Power wire Ran to
Amp rack


60 Amp Fuse




TXD3204 4 Channel Amp & TXD1000.1 Subwoofer amp

Power/Fuse Layout

Connects to Battery



30 Amp Fuse



60 Amp Fuse

