



# 2020+ Toyota Highlander

Add amplifier(s) to stock stereo - fast & easy!


- No cutting or splicing factory wires!
- No need to run new speaker wires!
- Works with most amplifier brands.
- Works with aftermarket stereos also!



**Plug & Play  
Harnesses**



# How to connect tacotunes plug & play wiring to: AudioControl LC5i Pro




**NOTE: The input / output signal(s) have a few options.  
The settings above are summing all channels for full range to  
all outputs**

**Connect to LC5i  
(Color coded  
Installation)**





**Connect to  
Amplifier(s)**

# How to connect Audio Control LC5i Pro to amplifiers



# 4 Channel & Subwoofer amplifier overview




Connect to harness 3.

Power Wire:

From battery / distribution block.  
Important: Check with your amp manufacturer  
for the proper gauge & fuses

Tuning/Configuration knobs & switches:  
Check out our video(s) on how to properly  
adjust these settings.



Subwoofer Output


[Link to YouTube Channel](#)

# 2020+ Toyota Highlander

## How to add amplifiers to stock stereo in your Highlander using an LC5i Pro.



Plug and Play, easy install,  
no need to run new speaker wire.

Plug & Play Speaker Harnesses next page.



**NOTE: The input / output signal(s) have a few options. The settings above are summing all channels for full range to all outputs**

**NOTE: 100 WATTS RMS X4 MAX POWER - CHECK AMP FOR RMS RATINGS DO NOT USE "PEAK" RATINGS**



[CLICK HERE FOR HARNESSSES](#)

# 2020+ Toyota Highlander

Stock speaker location overview / plug & play harnesses.

Be sure to check out our video(s) that show you how to easily upgrade the speakers in your **Highlander!**

We will explain how your Toyota is configured from the factory AND show you how to easily upgrade your speakers without any cutting or splicing - ANY of your factory wires!

