How to add aftermarket Amplifiers to

2024+ Tacoma

Non JBL : ANC Equipped










LC5i Pro

Using tacotunes

TXD20005v2


2024+ Toyota Tacoma

2024+ NON-JBL Toyota Tacoma ANC Equipped Plug & Play Harness




Connect Harness 1 To Factory Wiring

Factory ANC Module
REMOVED FROM VEHICLE



TACO TUNES




Connect Harness Extensions
(Speaker & 12v Signals)


2024+ Toyota Tacoma

2024+ NON-JBL Toyota Tacoma Plug & Play Harness

TACO TUNES

Amp Input Side





Do NOT use black from harness leads for ground.

Ground LC5i Pro to vehicle Chassis.

Remote Turn On Wire
Connects to Amplifier REM

TXD20005v2 Amplifier using


Lc5i Pro

2024+ Toyota Tacoma

2024+ NON-JBL Toyota Tacoma Plug & Play Harness

TACO TUNES

Amp Output Side



Output Wires

Remote Turn On Wire
Connects to
LC5i REM OUT

TXD20005v2 Amplifier using

Lc5i Pro

2024+ Toyota Tacoma

2024+ NON-JBL Toyota Tacoma ANC Equipped Plug & Play Harness

TACO TUNES

Factory Wiring

Output Wires

+12V REM GND

PWR PRT

FL FR RL RR SUB

WHITE/BLACK WHITE GREY/BLACK GREY GREEN/BLACK GREEN PURPLE/BLACK PURPLE

FRONT REAR

FRONT L REAR L SUB L 4CH 5CH SENS CLIP HPF SENS CLIP HPF

MIN MAX 40Hz 400Hz MIN MAX 40Hz 400Hz

FRONT R REAR R SUB R SENS LPF SUBSONIC BOOST

MIN MAX 50Hz 250Hz 10Hz 55Hz CLIP 0dB 12dB

REMOTE

SUBWOOFER

WHITE
WHITE / BLACK
GRAY
GRAY/BLACK
GREEN
GREEN / BLACK
PURPLE
PURPLE / BLACK

LC5i PRO

Six Channel Line-Output Converter
High Voltage Design with Impedance Matching
AccuBass®, GTOTM Signal Sensing, Signal Bus

Channel 1 Input
Channel 2 Input
Load Select 20 Ω 60 Ω 20 kΩ
Signal Bus SumBus Sep.
Level Max
Channel 1 Outputs
Channel 2 Outputs
Channel 3 Outputs
AccuBASS Level Threshold
AudioControl
Rmt Out
Rmt In
+12 V
Ground
Trigger Mode Rmt In GTO Audio
Ground Isolation GND ISO 200Ω
Power
Bass Level Control

Do NOT use black from harness leads for ground.

Ground LC5i Pro to vehicle Chassis.

TXD20005v2 Amplifier using

Lc5i Pro