

## 2019+ Toyota Corolla

Add amplifier(s) to stock stereo - fast & easy!




How to connect tacotunes plug & play wiring to: **Audio Control LC5i Pro** UNES TACO **Toyota Dashboard** Toyota Stereo **Rear View** TUNES **Stock wiring** tacotunes Harness 2 tacotunes **Harness 1** 17 Feet 17 Feet 16 Gauge 18 Gauge thicker than 18 Gauge tacotunes 17 Feet Harness 3 NOTE: The input / output signal(s) have a few options. The settings above are summing all channels for full range to all outputs **Front** WHITE **Connect to LC5i** WHITE / BLACK (Color coded Rear GREEN GREEN / BLACK **Installation)** Sub TACO TUNES **AudioControl Connect to Amplifier(s)** 

## **How to connect Audio Control LC5i Pro to amplifiers**




## 4 Channel & Subwoofer amplifier overview



**Tuning/Configuration knobs & switches:** 


Check out our video(s) on how to properly adjust these settings.




From battery / distribution block.
Important: Check with your amp manufacturer
for the proper gauge & fuses



**Link to YouTube Channel** 





## 2019+ Toyota Corolla

Stock speaker location overview / plug & play harnesses.

Be sure to check out our video(s) that show you how to easily upgrade the speakers in your Corolla! We will explain how your Corolla is configured from the factory AND show you how to easily upgrade your speakers without any cutting or splicing - ANY of your factory wires!

